CUSCO Rear Sway Bar Installation Manual

[Part #] : 429 311 B14 [Make: Model] : Mazda : ND5RC [Miata MX-5] [Position] : Rear [Part List] : Sway Bar ·····1 Bushings ·····2 Brackets ·····2 Installation Manual ·····1

 \triangle Caution Approximate installation time : 1 hour (Completion time is vary)

△Warning DO NOT install on unintended vehicles.

Congratulation on your CUSCO Product purchase.

Please read the followings before begin the installation. Please feel free to ask questions should you have. Please keep this installation manual for your record and pass this manual to the next owner if second hand sales occurred.

Quality control is our number one priority.

CUSCO is NOT responsible for any damages resulted by faulty use of this products.

·	
This pr	oduct is designed for use in Japan only.
lt m	ust not be used in any other country.

Please Read Carefully followings and understand that safety first and proper use of this product.


A Warning	Safety First!! Improper use of this product may result danger, and death.
A Caution	DO NOT install on unintended vehicles.

. .

 Drive sale with caution after the completion of this install. Follow the automotive manufacture recommended procedures and specifications. CUSCO is NOT responsible for any damages resulted by faulty use of this products. CusCo is NOT responsible for any damages resulted by faulty use of this products. Confirm the parts is designed for the model and make of your vehicle. DO NOT USE FOR UNINTENDED vehicles. Confirm the parts is designed for the model and make of your vehicle. DO NOT USE FOR UNINTENDED vehicles. Auranto USE FOR UNINTENDED vehicles. Auranto USE FOR UNINTENDED vehicles. Auranto Before Begin Installation Aways follow the automotive manufacture's procedures when installing CUSCO products. CUSCO products MUST be installed by trained and certified mechanics. Always ways afely gears when installing CUSCO products as followed: safety gloves, clothes, hats, and gve protection cover while installing CUSCO products as followed: safety gloves, clothes, hats, and gve protection cover while installing CUSCO products. Follow the procedure below in order to avoid injury. OTRN OFF an engine. QUSE AUTOMOTIVE Jacks, Liffs, and Jack Stands proper to vehicles weights. QUSE AUTOMOTIVE Jacks, Liffs, and Jack Stands proper to vehicles weights. QUSE AUTOMOTIVE Manufacture's recommended Jack points. Caution NOT to damage electric wires, connectors, and brackets. QUE Automotive Mounfacture's recommended tack points. Caution NOT modify and fabricate CUSCO products are not supplied with replacement hardwares. Replace with NeW OEM hardwares if damaged. FOLLOW the Automotive Manufacture's recommended torque specs. DO NOT modify and fabricate CUSCO products are not supplied with replacement hardwares. Folico W the procedure below befor	Follow the	steps below.
 Confirm parts list. Confirm the parts is designed for the model and make of your vehicle. DO NOT USE FOR UNITENDED vehicles. Alvance Before Begin Installation Always follow the automotive manufacture's procedures when installing CUSCO products. CUSCO products MUST be installed by trained and certified mechanics. Allow 24 hours to cool down a vehicle before start installation of CUSCO Parts. Always wear safety gears when installing CUSCO products as followed: safety gloves, clothes, hats, and eye protection cover while installing CUSCO products. Follow the procedure below in order to avoid injury. Place fender protection cover while installing CUSCO products. Follow the procedure below in order to avoid injury. OTURN OFF an engine. @Proceed on FLAT surface. @USE AUTOMOTIVE Jacks, Lifts, and Jack Stands proper to vehicles weights. @USE Automotive Manufacture's recommended Jack points. Caution with rough surfaces. Keep and Protect removed OEM parts during installations. Caution NOT to damage electric wires, connectors, and brackets. USE OEM bolts and nuts if CUSCO products are not supplied with replacement hardwares. Replace with NEW OEM hardwares if damaged. FOLLOW the Automotive Manufacture's recommended torque specs. OD NOT modify and fabricate CUSCO products during installation. Atter Installation and Before driving Check for lose parts. @Shift the gear to Neutral (N) or Parked (P) with Parking Brake ON. @Remove Jacks, Lift, and Jack Stands from a vehicle then confirm all 4 wheels touches ground. Regular Maintenance Inspect installed CUSCO parts regularly for safety and comfort. Drive with Caution, Sway bar changes handing characteri	∆ <mark>Warning</mark>	recommended procedures and specifications.
 Always follow the automotive manufacture's procedures when installing CUSCO products. CUSCO products MUST be installed by trained and certified mechanics. Allow 24 hours to cool down a vehicle before start installation of CUSCO Parts. Always wear safety gears when installing CUSCO products as followed: safety gloves, clothes, hats, and eye protections in order to avoid injury. Place fender protection cover while installing CUSCO products. Follow the procedure below in order to avoid injury. OTURN OFF an engine. QUSE AUTOMOTIVE Jacks, Lifts, and Jack Stands proper to vehicles weights. QUSE AUTOMOTIVE Jacks, Lifts, and Jack Stands proper to vehicles weights. QUSE AUTOMOTIVE Jacks, Lifts, and Jack Stands proper to vehicles weights. QUSE AUTOMOTIVE Jacks, Lifts, and Jack Stands proper to vehicles weights. QUSE AUTOMOTIVE Jacks, Lifts, and Jack Stands proper to vehicles weights. QUSE AUTOMOTIVE Jacks, Lifts, and Jack Stands proper to vehicles weights. QUSE AUTOMOTIVE Jacks, Lifts, and Jack Stands proper to vehicles weights. QUSE AUTOMOTIVE Jacks, USCO products are not supplied with replacement hardwares. Replace with NEW OEM hardwares if damaged. FOLLOW the Automotive Manufacture's recommended torque specs. DO NOT modify and fabricate CUSCO products during installation. After Installation and Before driving Check for loose parts. OCheck for leto ver tools and parts. QShift the gear to Neutral (N) or Parked (P) with Parking Brake ON. QRemove Jacks, Lift, and Jack Stands from a vehicle then confirm all 4 wheels touches ground. Regular Maintenance Inspect installed CUSCO prats regularly for safety and comfort. Drive with Caution, Sway bar changes handling characteristic of vehicles. Reoraque installed CUSCO parts regularly. Stop using CUSCO products with ne	∆ <mark>Caution</mark>	 Confirm parts list. Confirm the parts is designed for the model and make of your vehicle.
 Check for loose parts. Torque All bolts and nuts with Automotive manufacture recommended specifications. Follow the procedure below before starting the engine. @Check for left over tools and parts. @Shift the gear to Neutral (N) or Parked (P) with Parking Brake ON. @Remove Jacks, Lift, and Jack Stands from a vehicle then confirm all 4 wheels touches ground. Regular Maintenance Inspect installed CUSCO parts regularly for safety and comfort. Drive with Caution, Sway bar changes handling characteristic of vehicles. Re-Torque installed CUSCO parts regularly. Stop using CUSCO products if irregular vibrations, sound, and / or damaged, broken. Slowly park the vehicle if occurred while driving. Have a certified repair shop perform inspection of the vehicle. Replace defected products with new products if occurred. CUSCO is NOT responsible for cosmetic blemishes NOR functional claims. CUSCO in NOT responsible for ANY damages or accidents, ALL CUSCO products are OFF ROAD USE ONLY. 	∆Warning	 Always follow the automotive manufacture's procedures when installing CUSCO products. CUSCO products MUST be installed by trained and certified mechanics. Allow 24 hours to cool down a vehicle before start installation of CUSCO Parts. Always wear safety gears when installing CUSCO products as followed: safety gloves, clothes, hats, and eye protections in order to avoid injury. Place fender protection cover while installing CUSCO products. Follow the procedure below in order to avoid injury. OTURN OFF an engine. @Proceed on FLAT surface. @USE AUTOMOTIVE Jacks, Lifts, and Jack Stands proper to vehicles weights. @USE Automotive Manufacture's recommended Jack points. Caution with rough surfaces. Keep and Protect removed OEM parts during installations. Caution NOT to damage electric wires, connectors, and brackets. USE OEM bolts and nuts if CUSCO products are not supplied with replacement hardwares. Replace with NEW OEM hardwares if damaged. FOLLOW the Automotive Manufacture's recommended torque specs.
2/4	∆Warning	 Check for loose parts. Torque All bolts and nuts with Automotive manufacture recommended specifications. Follow the procedure below before starting the engine. OCheck for left over tools and parts. Shift the gear to Neutral (N) or Parked (P) with Parking Brake ON. Remove Jacks, Lift, and Jack Stands from a vehicle then confirm all 4 wheels touches ground. Regular Maintenance Inspect installed CUSCO parts regularly for safety and comfort. Drive with Caution, Sway bar changes handling characteristic of vehicles. Re-Torque installed CUSCO parts regularly. Stop using CUSCO products if irregular vibrations, sound, and / or damaged, broken. Slowly park the vehicle if occurred while driving. Have a certified repair shop perform inspection of the vehicle. Replace defected products with new products if occurred. CUSCO is NOT responsible for cosmetic blemishes NOR functional claims. CUSCO in NOT
		2/4


Removal of OEM Rear Sway Bar


- ① Remove Rear Tires.
- ② Remove nuts from both Left and Right sway bar links.
- ③ Remove both Left and Right sway bar brackets, bushings, then sway bar.



Rear Sway Bar Installation

Reverse the removal procedure for installation of supplied bushings, brackets, and nuts.





For Further Inquire CARROSSER Co. Ltd. oversea@cusco.co.jp (Asia, Oceania, Europe, Africa, and all other area) CUSCO USA, INC. Info@cuscousainc.com (North & South America)