## BRAKE CYLINDER STOPPER










BCS is rigidity parts for brake mastercylinder. Imporve brake feeling and direct touch feeling to be installed brake master cylinder.

## **WITH BCS**



## WITHOUT BCS

